

3. REFERENCES AND FEEDBACKS

The drive references are the following:

- Main speed/torque reference
- Speed/torque limit reference
- PID reference
- PID feedback

3.1. Main Speed/Torque Reference

If a speed control (e.g. **C011 = Speed** for Motor 1) is used, the main reference is a speed reference, while if a torque control is used (e.g. **C011=Torque** or **C011=Speed** for Motor 1, but the digital input is closed for the Slave programmed with C170), the main reference of the drive is a torque reference.

The main reference can be one of the following:

- Analog/digital inputs programmed as sources (see parameters **C143-C146** in the CONTROL METHOD MENU)
- PID output if **C294 PID Action = 1: [Reference]**
- Digital inputs programmed as Multispeed (see MULTISPEED MENU) only when the main reference is a speed reference.

3.2. Speed/Torque Limit Reference

If a speed control is used (e.g. **C011 = Speed** for Motor 1) and a VTC or FOC algorithm is used, you can program a source as an external torque limit (see parameter **C147** in the CONTROL METHOD MENU).

If a torque control is used and an external speed limit has been set up (e.g. **C011 = Torque with Speed Limit** for Motor 1) and a FOC algorithm is used, you can program one source as an external speed limit (see parameter **C147** in the CONTROL METHOD MENU).

3.3. PID Reference

If the internal PID regulator is enabled (**C291 different from Disabled**), its reference is given by default by the sum of the three sources programmed as references (see parameters **C285-C287** in the PID CONFIGURATION MENU).

Different types of PID reference control (Two PIDs and 2-zone mode) are available based on the setting in parameter **C291a** (PID Control Mode).

3.4. PID Feedback Reference

The PID feedback by default is the sum of the three sources programmed as feedback (see parameters **C288-C290** in the PID CONFIGURATION MENU).

Different types of PID feedback control (Two PIDs and 2-zone mode) are available based on the setting in parameter **C291a** (PID Control Mode).

7.2. “VTC” Control Algorithm

- 1) **Wiring:** Follow the instructions stated in the “Caution Statements” and “Installation” sections in the **Sinus Penta's Installation Instructions Manual**.
- 2) **Power on:** Power on the drive and do not close the link to the **START** input to prevent the motor from running.
- 3) **Parameter modification:** Access parameter **P000** (Key parameter) and set its code (default value: 00001). Select the Engineering access level setting P001= Eng. Use the **ESC**, **▲**, **▼** and **SAVE/ENTER** keys to access the programming parameters. Also refer to the Menu Tree.
- 4) **Supply voltage:** Set the real supply voltage for the drive. You can set either mains voltage range or the DC supply stabilized by a Regenerative Penta drive. To set the type of power supply for the drive, access the MOTOR CONFIGURATION MENU and set configuration parameter **C008** to the value corresponding to the installation concerned.
- 5) **Motor parameters:** Set **C010** (Control Algorithm) as VTC Vector Torque Control. Set the motor ratings as follows:
 - **C015** (fmot1) rated frequency
 - **C016** (rpmnom1) rated rpm
 - **C017** (Pmot1) rated power
 - **C018** (Imot1) rated current
 - **C019** (Vmot1) rated voltage
 - **C029** (Speedmax1) max. speed desired.

Also set **C022** (resistance of one stator phase for a star connection or one third of one phase resistance for a delta connection) and **C023** (stator leakage inductance of one phase for a star connection or one third of the leakage of one phase for a delta connection). The value for **C022** corresponds to half the resistance value measured with an ohm-meter between two phases of the motor. If values to be set for **C022** and **C023** are not known, motor autotune is required (see step 6), otherwise, go to step 7. Press **SAVE/ENTER** each time a new parameter is set.

- 6) **Autotune:** First remove the **ENABLE** command, then access the AUTOTUNE MENU and set **I073** [1: Motor Tune] and **I074** = [0: All Ctrl no rotation]. Use the **ESC** key to accept changes. Close the **ENABLE** command and wait until tune is complete (Warning “**W32** Open Enable” is displayed). The drive has computed and saved the values for **C022** (stator resistance) and **C023** (leakage inductance).

If alarm “**A097** Motor Wires KO” trips, check the motor wiring. If alarm “**A065** Autotune KO” trips, this means that the **ENABLE** command has opened before autotune was complete. In this case, reset the drive sending a command from terminal MDI3, or press the **RESET** key in the display/keypad and perform the autotune procedure again.

**NOTE**

With the Autotuning function, calculate the value of the leakage inductance (**C023**). From the resulting value, manually subtract the value in mH of the output inductance installed between the drive and the motor.

- 7) **Overload:** Set parameter **C048** in the LIMITS MENU based on the maximum torque that can be generated expressed as a percentage of the motor rated torque.
- 8) **Startup:** Activate the **ENABLE** input (terminal 15) and the **START** input (terminal 14) and send a speed reference. The RUN LED and REF LED will come on and the motor will start. Make sure that the motor is rotating in the correct direction. If not, set parameter **C014** (Phase Rotation) to [1:Yes], or open the **ENABLE** and **START** inputs, remove voltage from the drive and, after waiting at least 5 minutes, reverse two of the motor phases.

- 9) Speed regulator adjustment:** If overshoot occurs when the speed setpoint is attained or if a system instability is detected (uneven motor operation), adjust the parameters relating to the speed loop (SPEED LOOP AND CURRENT BALANCING MENU). Set the two parameters relating to integral time (**P125**, **P126**) as [Disabled] and set low values for the parameters relating to proportional gain (**P127**, **P128**). Set equal values for **P127** and **P128** and increase them until overshoot takes place when the setpoint is attained. Decrease **P127** and **P128** by approx. 30%, then decrease the high values set for integral time in **P125** and **P126** (keep both values equal) until an acceptable setpoint response is obtained. Check to see if the motor runs smoothly at constant speed.
- 10) Possible failures:** If no failure occurred, go to step 11. Otherwise, check the drive connections paying particular attention to supply voltages, DC link and input reference. Also check if alarm messages are displayed. In the MEASURES MENU, check the speed reference (**M000**), the reference speed processed by the ramps (**M002**), the supply voltage of the control section (**M030**), the DC-link voltage (**M029**), the condition of the control terminals (**M033**). Check to see if these readouts match with the measured values.
- 11) Additional parameter modifications:** When parameter **P003** = Standby Only (condition required for changing C parameters), you can change **Cxxx** parameters in the CONFIGURATION menu only when the drive is DISABLED or STOPPED, whereas if **P003** = Standby + Fluxing, you can change **Cxxx** parameters when the motor is stopped but the drive is enabled.
- Before changing any parameters, remember that the correct code for parameter **P000** must be previously set up.
- You can write down any custom parameters in the table provided on the last pages of this Programming Manual.
- 12) Reset:** If an alarm trips, find the cause responsible for the alarm and reset the drive. Enable input MDI3 (terminal 16) for some time, or press the **RESET** key on the display/keypad.

13. INPUTS FOR REFERENCES MENU

13.1. Processing Speed/Torque References

The “**main reference**” is the value, at constant rpm, for the controlled physical variable (speed or torque) (M000, M007) “required” for the drive.

This reference is acquired by the drive only if the **START** command is active and the drive is **RUNNING**, otherwise it is ignored.

The **main reference** is the reference at constant rpm: when the drive is **RUNNING**, it will increment the speed or torque **set-point** which will reach the main reference with a timed ramp (see the RAMPS MENU).

The drive operating mode is factory-set to **MASTER** with a speed reference. In **SLAVE** mode, a torque reference is used; this operating mode may be configured for **VTC** control (Vector Torque Control) and **FOC** control (Field Oriented Control) only.

The **control algorithm** and the **MASTER/SLAVE mode** can be set for each of the 3 programmable motors, depending on which motor is active at that moment (motor 1, motor 2 or motor 3).

To enable the **SLAVE** mode, set the following parameters to **1** or **2**:

C011 (motor 1)

C054 (motor 2)

C097 (motor 3)

The **SLAVE** mode may also be selected through a digital input (see the DIGITAL INPUTS MENU).

When the main reference is acquired by the drive (**RUNNING** on), it becomes the reference for the time ramps generating the current speed/torque set-point for the connected motor.

The set up of the main reference is based on a number of parameters included in several menus:

Table 20: Parameters used for the Inputs for References Menu

Parameters	Menu	Contents
P050 ÷ P074	References	Scaling parameters for references sent from analog inputs REF, AIN1, AIN2. Scaling parameters for references sent from encoder and frequency input. Parameters for changes made using the UP and DOWN keys. Parameter for JOG reference setting. Parameter for drive disabling in case of reference at min. value.
P390 ÷ P399	References from option board	Scaling parameters for references sent from analog inputs XAIN4, XAIN5.
P080 ÷ P098	Multispeed	Parameters setting preset multispeed values to be selected through digital inputs.
P105 ÷ P108	Prohibit Speed	Parameters setting prohibit speed values.
P115 ÷ P121	Reference Variation Percent	Parameters setting slowing down values percent to be selected through digital inputs.
C143 ÷ C146	Control Method	Parameters setting the reference source.
C011, C028, C029	Configuration of Motor 1	Parameter setting the Master (speed) mode or the Slave (torque) mode. Parameters setting the min. speed or the max. speed.
C054, C071, C072	Configuration of Motor 2	
C097, C114, C115	Configuration of Motor 3	
C047, C048	Limit for Motor 1	Parameters setting the min. torque and the max. torque.
C090, C091	Limit for Motor 2	
C133, C134	Limit for Motor 3	

The following pages contain block diagrams illustrating speed reference processing (Figure 7) and torque reference processing (Figure 8). Menus and parameters used are also stated.

Speed Reference computing




Figure 7: Speed Reference computing

Torque Reference computing




Figure 8: Torque Reference computing

32.1.8. Torque Control (VTC and FOC Only)

VTC and FOC controls allow controlling the drive with a torque reference instead of a speed reference. To do so, set [1: Torque or 2: Torque with Speed Limit [FOC only] in the relevant parameter (**C011** for motor 1, **C054** for motor 2, **C097** for motor 3).

In this way, the main reference corresponds to the motor torque demand and may range from **C047** to **C048 (Limits Menu)** for motor 1 (minimum and maximum torque expressed as a percentage of the motor rated torque). For motors 2 and 3, the parameters relating to min. and max. torque (**C090**, **C091** and **C133**, **C134**) are included in the Limits Menu 2 and Limits Menu 3.

Using a 0020 drive connected to a 15kW motor, **C048** is factory-set to 120% of the motor rated torque. If the max. reference is applied (**C143** = REF), the torque reference will be 120%.

If a 7.5kW motor is connected, **C048** may exceed 200%; torque values exceeding 200% may be obtained based on the value set in **C048**.

The motor rated torque results from the following formula:

$$C = P / \omega$$

where P is the rated power expressed in W and ω is the rated speed of rotation expressed in radians/sec.

Example: the rated torque of a 15kW motor at 1420rpm is equal to:

$$C = \frac{15000}{1420 \cdot 2\pi / 60} = 100.9 \text{ Nm}$$

The starting torque is:

$$\text{rated torque} \cdot 120\% = 121.1 \text{ Nm}$$

32.2. List of Parameters C008 to C128**Table 71: List of parameters C008 to C128**

Parameter		FUNCTION	User Level	MODBUS Address	DEFAULT VALUES
C008		Rated mains voltage	BASIC	1008	2:[380÷480V]
C009		N. of configured motors	ENGINEERING	1009	1

Parameter		FUNCTION	User Level	MODBUS Address	DEFAULT VALUES
C010	M1	Type of control algorithm	BASIC	1010	0: IFD
C053	M2			1053	
C096	M3			1096	
C011	M1	Type of reference	ADVANCED	1011	0: Speed (MASTER mode)
C054	M2			1054	
C097	M3			1097	
C012	M1	Speed feedback from encoder	BASIC	1012	0: No
C055	M2			1055	
C098	M3			1098	
C013	M1	Type of V/f curve	BASIC	1013	See Table 75 and Table 79
C056	M2			1056	
C099	M3			1099	
C014	M1	Phase rotation	ENGINEERING	1014	0: No
C057	M2			1057	
C100	M3			1100	
C015	M1	Rated motor frequency	BASIC	1015	50.0 Hz
C058	M2			1058	
C101	M3			1101	
C016	M1	Rated motor rpm	BASIC	1016	1420 rpm
C059	M2			1059	
C102	M3			1102	
C017	M1	Rated motor power	BASIC	1017	See Table 76 and Table 80
C060	M2			1060	
C103	M3			1103	
C018	M1	Rated motor current	BASIC	1018	See Table 76 and Table 80
C061	M2			1061	
C104	M3			1104	
C019	M1	Rated motor voltage	BASIC	1019	Depending on the drive voltage class
C062	M2			1062	
C105	M3			1105	
C020	M1	Motor no-load power	ADVANCED	1020	0.0%
C063	M2			1063	
C106	M3			1106	
C021	M1	Motor no-load current	ADVANCED	1021	0%
C064	M2			1064	
C107	M3			1107	
C022	M1	Motor stator resistance	ENGINEERING	1022	See Table 76 and Table 80
C065	M2			1065	
C108	M3			1108	
C023	M1	Leakage inductance	ENGINEERING	1023	See Table 76 and Table 80
C066	M2			1066	
C109	M3			1109	
C024	M1	Mutual inductance	ADVANCED	1024	250.00mH
C067	M2			1067	
C110	M3			1110	

C025	M1	Rotor time constant	ADVANCED	1025	0 ms
C068	M2			1068	
C111	M3			1111	
C026	M1	Time constant of bus voltage low-pass filter	ENGINEERING	1026	0 ms
C069	M2			1069	
C112	M3			1112	
C028	M1	Min. motor speed	BASIC	1028	0 rpm
C071	M2			1071	
C114	M3			1114	
C029	M1	Max. motor speed	BASIC	1029	1500 rpm
C072	M2			1072	
C115	M3			1115	
C030	M1	Flux weakening speed	ENGINEERING	1030	90%
C073	M2			1073	
C116	M3			1116	
C031	M1	Max. speed alarm	ADVANCED	1031	0: Disabled
C074	M2			1074	
C117	M3			1117	
C032	M1	Reduction in quadratic torque curve	ADVANCED	1032	30%
C075	M2			1075	
C118	M3			1118	
C033	M1	Frequency of maximum reduction in quadratic torque curve	ADVANCED	1033	20%
C076	M2			1076	
C119	M3			1119	
C034	M1	Voltage Preboost for IFD	BASIC	1034	See Table 75 and Table 79
C077	M2			1077	
C120	M3			1120	
C034a	M1	VTC Torque boost for positive reference	ENGINEERING	1204	0%
C077a	M2			1206	
C120a	M3			1208	
C034b	M1	VTC Torque boost for negative reference	ENGINEERING	1205	0%
C077b	M2			1207	
C120b	M3			1209	
C035	M1	Voltage Boost0 at programmable frequency	ADVANCED	1035	See Table 75 and Table 79
C078	M2			1078	
C121	M3			1121	
C035a	M1	Boost0 application frequency	ADVANCED	1027	5%
C078a	M2			1070	
C121a	M3			1113	
C036	M1	Voltage Boost1 at programmable frequency	ADVANCED	1036	See Table 75 and Table 79
C079	M2			1079	
C122	M3			1122	
C037	M1	Boost1 application frequency	ADVANCED	1037	See Table 75 and Table 79
C080	M2			1080	
C123	M3			1123	
C038	M1	Autoboost	ADVANCED	1038	See Table 75 and Table 79
C081	M2			1081	
C124	M3			1124	
C039	M1	Slip compensation	ADVANCED	1039	0: Disabled
C082	M2			1082	
C125	M3			1125	
C040	M1	Voltage drop at rated current	ADVANCED	1040	0: Disabled
C083	M2			1083	
C126	M3			1126	

C041	M1	Fluxing ramp time	ENGINEERING	1041	See Table 74 and Table 78
C084	M2			1084	
C127	M3			1127	
C042	M1	Vout saturation percentage	ENGINEERING	1042	100%
C085	M2			1085	
C128	M3			1128	

C008 Rated Mains Voltage

C008	Range	0 ÷ 8	0: [200 ÷ 240] V 1: 2T Regen. 2: [380 ÷ 480] V 3: [481 ÷ 500] V 4: 4T Regen. 5: [500 ÷ 600] V 6: 5T Regen. 7: [600 ÷ 690] V 8: 6T Regen.
	Default	2	2: [380 ÷ 480] V
	Level	BASIC	
	Address	1008	
	Function	This parameter defines the rated voltage of the mains powering the drive, thus allowing obtaining voltage ranges to be used for the drive operation. The value set in this parameter depends on the Drive voltage class . To supply the drive via a non-stabilized DC source, the corresponding AC voltage range must be used (see Table 72). DO NOT USE xT Regen settings in this case.	

Table 72: Equivalence between AC mains range and DC range

AC Mains	DC range
200÷240 Vac	280÷338 Vdc
380÷480 Vac	530÷678 Vdc
481÷500 Vac	680÷705 Vdc
500÷600 Vac	705÷810 Vdc
600÷690 Vac	810÷970 Vdc



NOTE

Select xT Regen (where x relates to the voltage class of the drive) **if the drive is DC-supplied through a regenerative Sinus Penta or a different drive used to stabilize the DC bus to a higher level than the stabilization level obtained when rectifying the 3-phase mains.**

C009 N. of Configured Motors

C009	Range	1÷3	1÷3
	Default	1	1
	Level	ENGINEERING	
	Address	1009	
	Function	This parameter determines the number of motors to be configured. The active motor is selected through digital inputs programmed with C173 and C174 (see the DIGITAL INPUTS MENU). The programming parameters of the Motor Control 2 Menu can be accessed only if C009 = 2 or 3; the programming parameters of the Motor Control 3 Menu can be accessed only if C009 = 3.	